

Power on/off APEmille racks in Zeuthen

Dirk Pleiter

25 October 2006

1 Power on

1. Switch on main fuse (upper position=on).
2. Switch on fuses for upper and lower crate.
3. Press button on PSU control box. This will first remove the inhibit signal of the upper and then the lower crate.
4. Monitor LEDs of power supplies. If one of them remains red, press button on PSU control box to switch off (alternatively: use fuses to switch off upper and lower crate).

Important: The upper crate must be powered on first, because it provides the clock to the lower crate.

2 Power off

1. Press button on PSU control box. This will switch off first the lower and then the upper crate.
2. Switch off the fuses including the main fuse (lower position=off)