

Power on/off apeNEXT racks in Zeuthen

Dirk Pleiter

20 February 2006

1 Power on

1. Press *power host system* switch for several seconds:
 - Watch *host system PSU status* LED
 - Wait until blades booted
2. Switch-on *power upper crate* (upper position=on)
 - Check fans/air flow of upper crate
 - Check status boards upper crate at front side: > 1 LED per board should be on

Switch-off upper crate and contact experts in case of problems. Do not proceed switching-on lower crate.

3. Switch-on *power lower crate* (upper position=on)
 - Check fans/air flow of upper crate
 - Check status boards lower crate at front side: > 1 LED per board should be on

Switch-off lower crate and contact experts in case of problems.

2 Power off

1. Switch-off *power lower crate* (lower position=off)
2. Switch-off *power upper crate* (lower position=off)
3. Press *power host system* switch for several seconds until *host system PSU status* LED are off